
TZ VIBE

TRANSIMPEDANCE PHONO PREAMP



Quick Start Guide

You can find a detailed owner's manual for download at <https://sutherlandengineering.com/products/tz-vibe>

Installation of the TZ VIBE is very straightforward:

Signal leads from your turntable attach to the two RCA jacks centrally located on the back panel. The ground wire from your turntable attaches to the ground screw in the middle.

The output of the **TZ VIBE** comes from the outer pair of RCA jacks on the back panel. Those interconnecting cables feed into the line-level input of your preamplifier or integrated amplifier.

Power to the **TZ VIBE** is provided with the supplied 48 volt outboard power supply module. Power requirements are very specific. **Do not make any substitution. Do not use the 48 volt power supply with any of your other electronics.**

Place the ferrite filter element within the power entry opening on the bottom of the **TZ VIBE**.

This unit is to be used only with Moving Coil cartridges.